


HOLCIM CIRCULATION PLAN





















Assembly Point





6 BEMTI

















In case of emergency 0032 (0)65 358 333

A IN + AREA 'WEIGHING BRIDGE' + AREA 'SAMPLING BRIDGE'







B AREA '6 BEMTI'













C AREA 'WEIGHING BRIDGE' + EXIT



